



QUICK REFERENCE

Gates-Hillman 4101

CONNECTING

Wired

Connect the appropriate cable to your device.



PRESENTING

Touch Panel

Share a device to the screen.



Tap  to refresh the touch panel. Turn  off when complete.