QUICK REFERENCE
Porter Hall 125B

CONNECTING

Wired
Connect the appropriate cable to your device.

Wireless
1. Tap **Wireless Presentation** on the panel.

2. Follow the steps on the screen to **connect your device**.

3. Tap **End Presentation** to disconnect.

- Document camera
- Your device
- Touch panel
- Auxiliary panel
- Blu-ray

Device cables

HDMI Cable   VGA Cable   3.5mm Audio Jack

PRESENTING

Touch Panel
⌂ *Tap to refresh the touch panel.*
⏻ *Turn off when complete.*

1 Tap to start

2 Turn on/off

Turn System Off   **Carnegie Mellon University**

DEVICES	CONTROLS	ACTIONS

Display Controls — **Set display options**

Turn On   Blank Screen   Screen Up   Screen Down

Device Controls — **Set device options**

Laptop
Document Camera
Blu-ray Player
3 Select device
Auxiliary Input
Wireless Presentation

Adjust lights/shades

Adjust lights/shades

Lights/Shades   **Adjust volume**   Advanced Audio

CRESTRON

NEED HELP?
412-268-8855 or mediatech@cmu.edu