QUICK REFERENCE

Wean 8427

CONNECTING

Wired

Connect the appropriate cable to your device.

Wireless

- 1. Tap Wireless Presentation on the panel.
- 2. Follow the steps on the screen to **connect** your device.
- 3. Tap **End Presentation** to disconnect.



PRESENTING

Touch Panel

a Tap to refresh the touch panel.

U Turn off when complete.

