

# QUICK REFERENCE

Wean Hall 5304

## CONNECTING

### Wired

1. Connect the **HDMI cable** to your laptop.
2. Tap **Laptop** on the panel.
3. Connect the **USB cable** to use the conference camera and microphone.



USB Cable



HDMI Cable

### Wireless

1. Tap **Wireless Presentation** on the panel.
2. Follow the steps on the screen to connect your device.
3. Tap **End Presentation** to disconnect.

## PRESENTING

### DISPLAY ONE DEVICE

1. Tap the touch panel.
2. Under **Devices**, tap the device that you want to display.

### USE HYBRID TEACHING TECHNOLOGY

1. Connect the **USB cable** to your laptop to use the conference camera and microphone.
2. Start a **Zoom** meeting on your computer.
3. Use the **Zoom app** to:
  - change the audio and video settings for the conference camera and microphone.
  - share your screen.

**NOTE:** For additional information on using Hybrid Teaching Technology, visit [cmu.edu/computing/start/teaching/standard-hybrid.html](https://cmu.edu/computing/start/teaching/standard-hybrid.html)



The screenshot shows the presentation control interface with the following elements and callouts:

- 1 Tap to start:** Points to the power icon and "Turn System On" text at the top left.
- 2 Select device:** Points to the "Doc Cam" button in the "DEVICE" column.
- 3 Set display:** Points to the "Display Controls" section, which includes "Turn Off", "Blank Screen", "Screen Up", and "Screen Down" buttons.
- Adjust volume:** Points to the volume slider at the bottom.

The interface also includes a "Wireless Presentation" button in the "DEVICE" column, a "Laptop" button, and a "Blu-ray Player" button. The "CONTROLS" section also includes "Device Controls" and a warning message: "Select a device on the left to start the system." The "ACTIONS" column is currently empty. The bottom bar includes "Lights", "Advanced Audio", and a volume slider.