QUICK REFERENCE

Wean Hall 5310

CONNECTING

Wired

- 1. Connect the **HDMI cable** to your laptop.
- 2. Tap **Laptop** on the panel.
- 3. Connect the **USB cable** to use the conference camera and microphone.





Wireless

- 1. Tap Wireless Presentation on the panel.
- 2. Follow the steps on the screen to connect your device.
- 3. Tap **End Presentation** to disconnect.

PRESENTING

DISPLAY ONE DEVICE

- 1. Tap the touch panel.
- 2. Under **Devices**, tap the device that you want to display.

USE HYBRID TEACHING TECHNOLOGY

- 1. Connect the **USB cable** to your laptop to use the conference camera and microphone.
- 2. Start a **Zoom** meeting on your computer.
- 3. Use the **Zoom app** to:
 - change the audio and video settings for the conference camera and microphone.
 - share your screen.

NOTE: For additional information on using Hybrid Teaching Technology, visit **cmu.edu/computing/start/teaching/standard-hybrid.html**

