# **QUICK REFERENCE**

Gates-Hillman 4215

## CONNECTING

### WIRED

- 1. Connect the HDMI cable to your laptop.
- 2. Tap **Laptop** on the panel.
- 3. Ensure audio output is set to **Crestron (HDMI)** to hear audio through the room speakers.

#### WIRELESS

- 1. Tap **Wireless Presentation** on the panel.
- 2. Follow the steps on the screen to connect your device.
- 3. Tap End Presentation to disconnect.



**Note:** Please bring the appropriate cables to use the auxiliary panel inputs.

### PRESENTING

### **TOUCH PANEL**

### **DISPLAY MULTIPLE DEVICES**

- 1. Under **Display Controls**, tap the location for the additional device.
- 2. Under **Devices** tap the additional device to display (i.e., Desktop, Document Camera, etc.).

Tap to start

3. (Optional) Under **Display Controls**, tap **Blank Screen/Unblank Screen** to toggle on/off room screens in the corresponding location.

### **USE HYBRID TEACHING TECHNOLOGY**


**IMPORTANT:** Use the panel to connect to Zoom, not your laptop.

- 1. Tap **Conferencing** on the touch panel and then **Zoom App**.
- 2. Tap **Join** and then enter the **Meeting ID and Passcode** from the meeting invite.
- 3. Use the Zoom Controls on the touch panel's **Zoom App** screen to control volume, record, chat, invite, etc.
- 4. Tap **End** to end the meeting.

Refer to the **ZOOM TEACHING SUPPORT GUIDE** in this room for steps on using the Zoom technology including sharing and camera controls. Find the guide online at: **cmu.edu/computing/ start/teaching/resident-hybrid-zoom.html** 



UTurn Syste	o On Carnegie Me	ellon University
DEVICE	CONTROLS	ACTIONS
Laptop	Display Controls Set display option	S
	Both (Powered off)	



Carnegie Mellon University

**Computing Services** 

#### NEED HELP? 412-268-8855 or mediatech@cmu.edu